

Quick guide to unlock the full pressure of the WASHR PRO

STEP 1



Remove the lime adjustment knob by spinning the knob anti clockwise until the knob has been removed.

STEP 3



Undo the fastening screw (highlighted) with an allen key (size 2.0) to allow the adjustment ring to be lowered.

Spin the adjustment ring anti clockwise to the lowest position.

Once at the lowest position, rotate the ring two revolutions clockwise and retighten the fastening screw with the allen key.

STEP 2



A black spring will be visible, you can leave it in place or remove it before the next step.

STEP 4



Place the lime adjustment knob back on top of the spring and tighten in a clockwise motion until the knob can't turn anymore.