INSTRUCTIONS FOR USE:

Thank you for purchasing the Bigboi PRO+! Before you start enjoying the features and benefits of touchless drying, please take a minute to read the below to familiarise yourself with the dryer.

IN THE BOX

- Bigboi Blower PRO +
- 9-meter hose
- 1 replacement filter
- 2 hose nozzles
- 1 cable management system
- 1 remote control

SET UP

- 1. Open the dryer box and take out the dryer.
- 2. Check its appearance to ensure no damage.
- 3. Connect the hose by fastening it clockwise.
- 4. Plug in the dryer to your power outlet (ensure the power supply voltage for your country matches the dryer)
- 5. Turn the dryer on via the switch and adjust to your desired wind speed and temperature.
- 6. You can start enjoying the touchless drying process!

IMPORTANT NOTICE

- 1. This machine uses a AC power
- 2. To maintain smooth air flow, please keep a safe distance from the drying surface. This will allow the warm filtered air to travel smoothly over a larger surface, making the drying process more efficient and from taking in any water which may damage the machine.
- 3. Clean the filters regularly to ensure smooth air flow.
- 4. Do not allow minors to use or be close to the machine without adult supervision!

MAINTENANCE INSTRUCTION

- 1. The shell of the machine can be cleaned with a soft cloth and neutral detergent solution (to avoid spoiling the paint work) then use a dry cloth to clean.
- 2. Use water or a strong fan to clean the filters regularly. Note that filters cannot be fixed on the machine until it is totally dry as the water may damage the machine. The machine has a standby filter packaged with it.
- 3. When the machine runs out of carbon brushes, please contact a professional to check and update the required parts.

For further information on any Bigboi products please contact sales@ibigboi.com

BIGBOI BLOWR PRO PLUS

INSTRUCTION MANUAL

BLOW PRO+




TOUCHLESS CAR, MOTORCYCLE & MARINE DRYER

STRUCTURE REPRESENTATION

NO.	Name	Amount
1	Nozzle	2
2	Nozzle handle	1
3	Screwed joint	1
4	Hose	1
5	Front cover	1
6	Damper components	2
7	Bracket	2
8	Motors	2
9	Anti-vibration pad	1
10	Case component	2
11	Noise elimination cover	2
12	Filters	2
13	Inlet cover	1
14	Trail cover	2
15	Cable management system	1
16	Trail nut	1
17	ON/OFF Select 1/2 motor	1
18	Operation light	1
19	Selectable wind speed	1
20	Operation light	1
21	Adjustable speed control	1



Lithium button battery 3.6V,2032



PRODUCT FEATURES

FUNCTIONS & FEATURES

Soft Start

Thanks to the protection from current buffers, when the dryer starts, the dryers will not discharge any impulse current, exerting no adverse influence upon the neighboring working electrical equipment.

Low Noise and Powerful Airflow

The specially designed noise reduction system will allow greater airflow than any other twin-commercial grade motor dryer, with up to (3200 watts) MAX subject to your region. This model can dry your car, motorcycle, boat or ski faster, in an environment with lower noise which will benefit the operator.

Remote function

Select your motor preference (1 or 2 motors). Select 'adjustable' in the air speed location on the machine. When selected press the POWER button on the remote to turn the unit on. The motors will activate, and you have 4 preset wind setting that you can toggle up and down. When you are done, you can turn the unit off by pressing the power button on the remote.

PLEASE NOTE: Turning the unit OFF via the remote will only place the unit in standby mode. To shutdown the unit completely bigboi recommends you to place the dryer's adjustment switch back to the O position.

BBT (Bigboi Temperature Technology)

Adjustable warm filtered air set at 20c higher than the surrounding environment. All this available at a touch of your fingertips.

Adjustable wind control

With the center piece of the control panel (showcasing the bigboi logo) is the wind control knob. This knob will allow the user to adjust the wind speed to their desired speed of up to 290km/h.

Selectable control

You can select from 3 different wind control settings. 1 is full speed, which will automatically use the full power of the motor selected. 2 is the adjustable mode, where you can change to your desired wind speed via the control knob on the unit or by pressing the power button on your remote enabling the 4 set wind speed on the remote control.

Accessories

Visit your supporting countries distributor website to see how you can make your dryer even more awesome with added accessories.